

INSTRUCTION MANUAL

当社製品をお買いあげいただきまして、ありがとうございます。CTSSユニットTSU-3/TSU-4は、67.0～250.3Hzの間で37波のサブトーンが選べます。組み込み、および操作については、本体の取扱説明書をご覧ください。

■ 付属品

基板ガイド…………… 2個 スポンジ…………… 1個
周波数表…………… 1部 取扱説明書…………… 1部
(TSU-3のみ)

■ トーン周波数


周波数	コード	1	2	3	4	5	6
67.0Hz	0	1	0	0	0	0	1
71.9Hz	1	1	0	0	0	0	1
74.4Hz	0	0	1	0	0	0	1
77.0Hz	1	0	1	0	0	0	1
79.7Hz	0	1	1	0	0	0	1
82.5Hz	1	1	1	0	0	0	1
85.4Hz	0	0	0	1	0	0	1
88.5Hz	1	0	0	1	0	0	1
91.5Hz	0	1	0	1	0	0	1
94.8Hz	0	1	1	0	0	0	0

周波数	コード	1	2	3	4	5	6
100.0Hz	1	1	1	0	0	0	0
103.5Hz	0	0	0	1	0	0	0
107.2Hz	1	0	0	1	0	0	0
110.9Hz	0	1	0	1	0	0	0
114.8Hz	1	1	0	1	0	0	0
118.8Hz	0	0	1	1	0	0	0
123.0Hz	1	0	1	1	0	0	0
127.3Hz	0	1	1	1	0	0	0
131.8Hz	1	1	1	1	0	0	0
136.5Hz	0	0	0	0	1	0	0

周波数	コード	1	2	3	4	5	6
141.3Hz	1	0	0	0	0	1	0
146.2Hz	0	1	0	0	0	1	0
151.4Hz	1	1	0	0	0	1	0
156.7Hz	0	0	1	0	0	1	0
162.2Hz	1	0	1	0	0	1	0
167.9Hz	0	1	1	0	0	1	0
173.8Hz	1	1	1	0	0	1	0
179.9Hz	0	0	0	1	0	0	0
186.2Hz	1	0	0	1	0	0	0
192.8Hz	0	1	0	0	1	0	0

周波数	コード	1	2	3	4	5	6
203.5Hz	1	1	0	1	1	0	0
210.7Hz	0	0	1	1	1	0	0
218.1Hz	1	0	1	1	1	0	0
225.7Hz	0	1	1	1	1	0	0
233.6Hz	1	1	1	1	1	0	0
241.8Hz	0	0	0	0	0	0	1
250.3Hz	1	0	0	0	0	0	1

How to set
the DIP switch.
(TSU-3 only)



Thank you for purchasing this product.

The TSU-3/TSU-4 provides any one of 37 possible tones from 67.0 to 250.3Hz. Installation and operation instructions are provided in the instruction manual of the radio.

■ Accessories

Bracket …………… 2 Foam cushion…………… 1
Frequency chart Instruction manual …… 1
(TSU-3 only) …………… 1

■ Tone Frequencies